

# **ALERTER NULLIFICATION**

## **SD-60, SD-60M OR SD-75M LOCOMOTIVES WITH ROUND ANALOG AIR GAUGES**

### **(Conventional Operation)**

1. **ISOLATE** all locomotives at control panel, generator field **OFF**, **CENTER** and **REMOVE** reverser.
2. Automatic brake valve handle in **RELEASE** position.
3. **CUT OUT** automatic brake valve.
4. Adjust regulating valve to 114 psi.
5. Automatic brake valve handle to **SUPPRESSION** position
6. **CUT IN** automatic brake valve to **PASS** position.
7. Ensure brake pipe pressure is at the required 90 psi.
8. Independent brake valve handle to **RELEASE** position.

11/6/2006