

AIR RECOVERY WHEN TRAIN IS SET UP FOR UNMANNED UNLOADING

EMD SD70ACE LOCOMOTIVES STARTING AT **9300
GE EVOLUTION LOCOMOTIVES STARTING AT **6097****

(Conventional or DP Operation)

1. **LEAVE** independent brake valve handle in **RELEASE** position.
2. Follow prompt; move automatic brake valve handle to **EMERGENCY** position. If no prompt visible, move automatic brake valve handle to **EMERGENCY** position.
3. Follow prompt; to clear emergency, move automatic brake valve handle to **RELEASE** position. If no prompt visible, wait 90 seconds, move automatic brake valve handle to **RELEASE** position.
4. PCS should reset and air restored to train. Independent brake cylinder pressure should go to 0 psi. **NOTE:** this may take a few minutes - especially in cold weather

11/21/2006