

# **IMPORTANT**

## **SPOTTING AT MIDWEST OR ALLOUEZ**

- When spotting DP trains at Midwest or Allouez ensure DP remote locomotive is placed in **REMOTE MODE IDLE**, not **remote mode isolate**. In isolate mode the automatic brake valve is cut out and only the lead DP consist is supplying air to the train. This could cause brakes to apply on rear of train, especially in cold weather.

11/6/2006