

ALERTER NULLIFICATION

EMD SD70ACE LOCOMOTIVES STARTING AT **9300 GE EVOLUTION LOCOMOTIVES STARTING AT **6097****

(Conventional or DP Operation)

1. If operating with Distributed Power, place DP remote locomotive in **REMOTE MODE IDLE**.
2. **ISOLATE** all locomotives on head end consist.
3. Generator field switch **OFF**.
4. Center and **REMOVE** reverser.
5. Release brakes.
6. If operating with Distributed Power, go to DP remote locomotive and **ISOLATE** at control panel before releasing train to Midwest or Allouez Taconite.

NOTE: As long as speed remains below 2 mph, alerter is nullified.

11/21/2006